



425-5015
'00+ Tahoe/Suburban
Silverado/Sierra

Installation Instructions



Remove all seat bolts from the driver and passenger seats. Use 9/16" socket for front bolts and 7/16" for rear bolts.



Remove the passenger seat from the vehicle for easier access when removing the middle jump seat. Unplug wiring harness under middle jump seat and remove middle jump seat.



Place legs on floor plate prior to mounting in vehicle and finger tighten nylock nuts to allow movement.

NOTE: Legs are marked on the bottom side indicating proper placement -- RR - Right Rear, RF - Right Front, LR - Left Rear, LF - Left Front).



Line up floor plate legs with mounting holes and tabs.



Secure the (8) 5/16" Nylock nuts with a 1/2" socket. When everything is in proper alignment, install passenger seat and replace factory OEM bolts.



Assemble the desktop stand to the mount base, starting with the vertical tube. Use clover knob to secure vertical tube to mount post.



Place articulated swing arm over the 5/8" end of the telescoping rod. Tighten with ratchet handle. Attach desktop to end of articulated swing arm and secure by tightening ratchet handle.

If you have questions or need further assistance please call Technical Support: 1.877.455.6886